

MODEL : 3321N, 3321W



**IMPORTANT - READ CAREFULLY BEFORE INSTALLING FIXTURE. RETAIN THESE INSTRUCTIONS FOR FUTURE REFERENCE.**  
 THIS PRODUCT MUST BE INSTALLED IN ACCORDANCE WITH THE NATIONAL ELECTRICAL CODE AND ALL APPLICABLE LOCAL CODES, BY A PERSON FAMILIAR WITH THE CONSTRUCTION AND OPERATION OF THE PRODUCT, AND THE HAZARDS INVOLVED. PROPER GROUNDING IS REQUIRED FOR SAFETY.  
**⚠️ DISCONNECT THE MAIN LINE BEFORE WIRING SECONDARY CONNECTORS.**

### CEILING INSTALLATION - TO REMOTE DRIVER (REM) 24V DC

- A- MAKE THE CUT-OUT OPENING FOR THE FIXTURE.
- B- MAKE ALL NECESSARY CONNECTIONS TO REMOTE DRIVER (**FOLLOWING POLARITY MARKING**) USING THE TWIST CONNECTORS (**NOT INCLUDED**)
- C- HOLD THE (2) CLIPS UPWARD AND INSERT FIXTURE INTO CUT-OUT.

