

MODEL : 2060R - NC / RF - 03 / 04 - LTE / D10 - 01

IMPORTANT - READ CAREFULLY BEFORE INSTALLING FIXTURE. RETAIN THESE INSTRUCTIONS FOR FUTURE REFERENCE.


THIS PRODUCT MUST BE INSTALLED IN ACCORDANCE WITH THE NATIONAL ELECTRICAL CODE AND ALL APPLICABLE LOCAL CODES, BY A PERSON FAMILIAR WITH THE CONSTRUCTION AND OPERATION OF THE PRODUCT, AND THE HAZARDS INVOLVED. PROPER GROUNDING IS REQUIRED FOR SAFETY.

NEW CONSTRUCTION WITH PLASTER FRAME (NC) / REMODEL (RF) INTEGRAL DRIVER (120V / 120-277V) DIMMING TRIAC/ELV OR 0-10V (15%)

A- REMOVE THE BOX PHILLIPS SCREW (**INCLUDED**) AND REMOVE THE COVER.B- INSTALL BX CABLE (**NOT INCLUDED**) USING BX CONNECTOR (**INCLUDED**). LEAVE AT LEAST 6" OF WIRE IN THE BOX.C- MAKE ALL NECESSARY CONNECTIONS (**SEE WIRING DIAGRAM**) USING QUICK CONNECTORS (**INCLUDED**) OR CONNECTION BLOCK.***DAISY CHAIN READY FOR LTE DIMMING ONLY.**



D- CLOSE THE CONNECTION BOX COVER AND TIGHTEN THE PHILLIPS SCREW.

A + B + C + D





WIRING DIAGRAM

DIMMING TRIAC/ELV (LTE)
120V ONLY
DAISY CHAIN READY



DIMMING 0-10V (D10)
120-277V
NO DAISY CHAIN




- E- MAKE THE CUT-OUT OPENING (SEE DIMENSIONS BELOW).
F- INSERT THE DRIVER INTO THE CUT-OUT.
G- HOLD THE (2) CLIPS UPWARD AND INSERT THE FIXTURE INTO THE CUT-OUT.
***DECORATIVE RING INSTALLATION (207X-XX-XX):**
HOLD THE FIXTURE'S (2) CLIPS UPWARD AND SET THE RING ONTO THE FIXTURE.


FOR MAINTENANCE, PULL THE FIXTURE OUT OF THE CUT-OUT.

E + F + G

Model	Plaster Frame	Cut-out dimensions (A)	Ceiling thickness	Clearance
2060R-03	BN-2060-03-NC	Ø2¼" (Ø55mm)	⅛"-⅜" (3-20mm)	4" (102mm)
2060R-04	BN-2060-04-NC	Ø3¼" (Ø80mm)		5" (127mm)




DECORATIVE RING (207X-XX-XX)



NEW CONSTRUCTION PLASTER FRAME INSTALLATION (NC)

- A- ENGAGE THE (4) HANGER BARS IN BOX SLOTS AVAILABLE AND CONNECT THEM TOGETHER.
B- FASTEN HANGER BARS TO CEILING BRACE WITH APPROPRIATE #8 SCREWS (**NOT INCLUDED**). THE PLASTER FRAME MUST BE FLUSH WITH CEILING BRACE AND INSURE THE SMALL FOLDED TABS ARE PLACED UNDER THE CEILING BRACES.

A**B**